Event-Metrics

Sensor

Power supply unit
and USB-C cable

USB-C must be connected to the power connection

LAN port can be used if Ethernet is available

Important: The appliance starts up as soon as the plug is disconnected from the power supply. If nothing lights up apart from PWR, press On/OFF until the LEDs flash green.

The 3G/4G LED should light up after approx. 1 minute.

No LED lights up: Unplug the sensor, leave it for 5 minutes and plug it in again.